


TWO LAYER LOADING METHOD FOR 2,500 LB. PALLETIZED SUPER-SACKS IN 50' 6" OR 60' 6" BOXCARS USING AIRBAGS AND 15" LATERAL VOID FILLER FOR LOAD SECUREMENT



NOTE AIR BAGS MUST NOT BE USED IN A VOID LARGER THAN 12", MUST BE INFLATED BETWEEN 8 & 10 PSI, MUST BE ADEQUATELY PROTECTED ON BOTH SIDES AND MUST NOT CONTACT FLOOR OF RAILCAR AFTER INFLATION.

