

Palletized Flat Stock Paper with Wood Floor Blocking

This method is for use with palletized / stretch wrapped units of flat stock paper and braced with 2" x 4" wooden floor blocking.

Each pallet is to be unitized with stretch-wrap in accordance with manufacturer's specifications.

Pallets are to be loaded in two sections in a 2-2 offset pattern. Should any single units be loaded in vehicle they should be centered laterally in the vehicle and braced on each side with 2" x 4" x 24" wooden "T" braces.

Lateral blocking of the two across pallets to consist of 2" x 4" x 24" wooden "T" braces applied to the side of each pallet adjacent to the lateral void.

Rear of load to be blocked longitudinally with laminated 2" x 4" x 96" cross block and two sets of laminated 2" x 4" x 18" back up cleats.

Notes

All floor blocking must be secured with 16D or larger nails placed every 6" in a staggered pattern.

See Page 2 for the BNSF Loading Schematic

