

Search for a Unit & Create a Pre-Gate



Unit Search

1.

Create Pre-Gate (Ingate & Outgate)

2.

Pre-Ingate
Use Seal Number

Pre-Outgate
Use Release Number

QR Code (Scan @ Kiosk or Enter RailPASS ID)

3.

Unit Status must be one of the following:

Pre-Ingate
(Not Ingated)

Pre-Outgate
(Ready for Pickup
On Ground)

QR Code scan at both
In-gate and Out-gate

After Ingating at kiosk, report parking location for units and chassis **IF DIFFERENT** from BNSF assigned location

Location Services must be turned on to use RailPASS

DOWNLOAD THE APP



1. Search for RailPASS
App is available for iPhone & Android
You can use Face ID or Touch ID to open the App



REGISTER & CREATE ACCOUNT

2. LOGIN / REGISTER **TAP** on Yes **COMPLETE SETUP** ★ **TAP** on OK **SET** Defaults

CDL or EMPLOYEE CODE
Use Number Entered at Kiosk

Most visited Hub
SCAC available from IANA based on Driver Registration
Unit Initial (helpful if same initial is always used)

APP OVERVIEW

3. ANDROID **iPHONE**

- 1 Search Units & Create (IN/OUT) Pre-Gates
- 2 Bobtail Pre-Gates
- 3 Units Pregated & Assigned to You are Listed
- 4 Refresh My Units List
- 5 Driver Dashboard
- 6 Emergency - Alert Hub Team & 911
- 7 More
 - a. Options
 - b. Support
 - c. Account

TOUCH ID / FACE ID

4.

Click on "More" on the Menu

Select "My Settings"

Tap on "Modify Defaults"

Toggle on "Use Face ID" or "Use Touch ID"

Location Services must be turned on to use RailPASS